



MOTOMANUAL

V190
GSM

motorola.com

HELLOMOTO

Introducing your new Motorola V190 GSM wireless phone. Here's a quick anatomy lesson.



Motorola, Inc.
Consumer Advocacy Office
1307 East Algonquin Road
Schaumburg, IL 60196

www.hellomoto.com

1-800-331-6456 (United States)

1-888-390-6456 (TTY/TDD United States for hearing impaired)

1-800-461-4575 (Canada)

Certain mobile phone features are dependent on the capabilities and settings of your service provider's network. Additionally, certain features may not be activated by your service provider, and/or the provider's network settings may limit the feature's functionality. Always contact your service provider about feature availability and functionality. All features, functionality, and other product specifications, as well as the information contained in this user's guide are based upon the latest available information and are believed to be accurate at the time of printing. Motorola reserves the right to change or modify any information or specifications without notice or obligation.

MOTOROLA and the Stylized M Logo are registered in the US Patent & Trademark Office. Java and all other Java-based marks are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and other countries. All other product or service names are the property of their respective owners.

© Motorola, Inc., 2005.

Manual Number: 6809496A31-0

contents

| | | | |
|-----------------------------------|-----------|---------------------------------|-----------|
| menu map | 5 | customize | 30 |
| essentials | 7 | ring style | 30 |
| about this guide | 7 | ring & event lights . . . | 31 |
| SIM card | 8 | time & date | 31 |
| battery | 8 | wallpaper | 32 |
| turn it on & off | 11 | screen saver | 32 |
| make a call | 11 | display appearance . . . | 33 |
| answer a call | 11 | answer options | 34 |
| store a phone number | 11 | calls | 35 |
| call a stored phone | | turn off a call alert . . . | 35 |
| number | 12 | recent calls | 35 |
| your phone number . . | 12 | redial | 36 |
| main attractions | 13 | return a call | 37 |
| play videos | 13 | caller ID | 37 |
| multimedia messages . | 14 | emergency calls | 37 |
| cable connections . . . | 16 | voicemail | 38 |
| basics | 17 | other features | 39 |
| display | 17 | advanced calling | 39 |
| menus | 20 | phonebook | 44 |
| text entry | 22 | messages | 48 |
| volume | 27 | instant messaging . . . | 50 |
| navigation key | 27 | chat | 52 |
| external display | 28 | personalizing | 52 |
| handsfree speaker . . . | 28 | call times & costs . . . | 54 |
| codes & passwords . . | 28 | handsfree | 55 |
| lock & unlock phone . . | 29 | data & fax calls | 56 |
| | | network | 57 |

| | |
|----------------------------------|-----------|
| personal organizer . . . | 57 |
| security | 59 |
| fun & games | 59 |
| service and repairs . . . | 62 |
| SAR Data | 63 |
| index | 65 |

menu map

main menu



Phonebook



Recent Calls

- Received Calls
- Dialed Calls
- Notepad
- Call Times *
- Call Cost *
- Data Times *
- Data Volumes *



Messages

- Create Message
- Message Inbox
- Voicemail
- Browser Msgs
- Info Services *
- Quick Notes
- Outbox
- Drafts
- MMS Templates



Tools

- SIM Tool Kit Apps *
- Calculator
- Datebook
- Shortcuts
- Alarm Clock
- Chat *
- Dialing Services
 - Fixed Dial *
 - Quick Dial
 - Voice Dial



Games & Apps



Web Access *

- Browser
- Web Shortcuts
- Stored Pages
- History
- Go To URL
- Browser Setup
- Web Sessions *



Multimedia

- Pictures
- Sounds
- Videos *



Ring Styles

- Style
- style Detail
- Ring Lights
- Event Lights



IM *

- Log In
- Offline Convs.
- IM Account
- Offline Settings
- Help



Settings

- (see next page)

* optional features

This is the standard main menu layout. Your phone's menu may be a little different.

settings menu



Personalize

- Home Screen
- Main Menu
- Color Style
- Greeting
- Wallpaper
- Screen Saver



Sync *



Call Forward *

- Voice Calls
- Fax Calls
- Data Calls
- Cancel All
- Forward Status



In-Call Setup

- In-Call Timer
- Call Cost Setup *
- My Caller ID
- Talk and Fax
- Answer Options
- Call Waiting



Initial Setup

- Time and Date
- 1-Touch Dial
- Display Timeout
- Backlight
- TTY Setup *
- Scroll
- Language
- Contrast
- DTMF
- Master Reset
- Master Clear



Phone Status

- My Tel. Numbers
- Credit Info/Available *
- Active Line *
- Battery Meter
- Other Information



Headset

- Auto Answer
- Voice Dial



Car Settings

- Auto Answer
- Auto Handsfree
- Power-Off Delay
- Charger Time



Network

- New Network
- Network Setup
- Available Networks
- My Network List *
- Service Tone *
- Network Jingle *
- Call Drop Tone



Security

- Phone Lock
- Lock Application
- Fixed Dial *
- Restrict Calls *
- Call Barring *
- SIM PIN
- New Passwords
- Certificate Mgmt *



Java Settings

- Java System
- Delete All Apps
- App Vibration
- App Volume
- App Priority *
- App Backlight
- Set Standby App *
- DNS IP *

* optional features



essentials



CAUTION: Before using the phone for the first time, read the *Important Safety and Legal Information* included in the gray-edged pages at the back of this guide.

about this guide

This guide shows how to locate a menu feature as follows:

Find it: Press  >  **Recent Calls** > **Dialed Calls**

This example shows that, from the home screen, you press the *menu key*  to open the menu. Scroll to and select  **Recent Calls**, then scroll to and select **Dialed Calls**.

Press the *navigation key*  to scroll to a menu feature. Press the *center key*  to select the highlighted menu feature.

symbols



This means a feature is network/subscription dependent and may not be available in all areas. Contact your service provider for more information.




This means a feature requires an optional accessory.

SIM card


Caution: Don't bend or scratch your SIM card. Keep it away from static electricity, water, and dirt.

Your *Subscriber Identity Module* (SIM) card contains personal information like your phone number and phonebook entries.


1




2



3




4




battery

battery installation


1



2




3



battery charging

New batteries are not fully charged. Plug the battery charger into your phone and an electrical outlet. Your phone might take several seconds to start charging the battery. Your display shows **Charge Complete** when finished.



Tip: Relax, you can't overcharge your battery. It will perform best after you fully charge and discharge it a few times.

Your phone has a light just below the external display that can pulse when you charge your battery. To turn this light on or off, see page 31.

You can charge your battery by connecting a cable from your phone's mini-USB port to a USB port on a computer. Both your phone and the computer must be turned on, and your computer must have the correct software drivers installed. Cables and software drivers are available in Motorola Original data kits, sold separately.



battery tips

Battery life depends on the network, signal strength, temperature, features, and accessories you use.

- Always use Motorola Original batteries and chargers. The warranty does not cover damage caused by non-Motorola batteries and/or chargers.
- New batteries or batteries stored for a long time may take more time to charge.
- When charging your battery, keep it near room temperature.
- When storing your battery, keep it uncharged in a cool, dark, dry place, such as a refrigerator.
- Never expose batteries to temperatures below -10°C (14°F) or above 45°C (113°F). Always take your phone with you when you leave your vehicle.
- It is normal for batteries to gradually wear down and require longer charging times. If you notice a change in your battery life, it is probably time to purchase a new battery.




Contact your local recycling center for proper battery disposal.

Warning: Never dispose of batteries in a fire because they may explode.


Before using your phone, read the battery safety information in the “Safety and General Information” section included in the gray-edged pages at the back of this guide.

turn it on & off

Caution: Some phones ask for your SIM card PIN code when you turn them on. If you enter an incorrect PIN code 3 times in a row, your SIM card is disabled and your display shows **SIM Blocked**. Contact your service provider.


To turn on your phone, press and hold  for a few seconds or until the display turns on. If prompted, enter your 6-digit SIM card PIN code and/or 4-digit unlock code.




To turn off your phone, press and hold  for 2 seconds.


make a call

Enter a phone number and press  to make a call.

To “hang up,” close the flip or press .

answer a call


When your phone rings and/or vibrates, just open the flip or press  to answer.

To “hang up,” close the flip or press .

store a phone number

You can store a phone number in your **Phonebook**:

- 1 Enter a phone number in the home screen.
- 2 Press the **Store** key.

3 Enter a name and other details for the phone number. To select a highlighted item, press the *center key* .



Note: You can store a phonebook entry on your phone or on your SIM card. In the entry, select **Store To** and choose **Phone** or **SIM**. Entries stored on the SIM card can only include name and number details.

4 Press the **Done** key to store the number.

To edit or delete a **Phonebook** entry, see page 44.

To store an email address, press  >  **Phonebook**, then press  > **New** > **Email Address**

call a stored phone number



Find it:  >  **Phonebook**


1 Scroll to the phonebook entry.




Shortcut: In the phonebook, press keypad keys to enter the first letters of an entry name, then press the **Search** key to jump to the entry.

2 Press  to call the entry.

your phone number

From the home screen, press   to see your number.

Tip: Want to see your phone number while you're on a call? Press  > **My Tel. Numbers**.

You can edit the name and phone number stored on your SIM card. From the home screen, press  ,  select an entry, and press the **Edit** key. If you don't know your phone number, contact your service provider.

main attractions


You can do much more with your phone than make and receive calls!

play videos

Find it: Press  >  **Multimedia** > **Videos** > *video name*



The video clip plays:



To download a video with the micro-browser, see page 60. You can also attach videos to multimedia messages.

multimedia messages

To create a group mailing list, see page 47. For more message features, see page 48.


send a multimedia message


A *Multimedia Messaging Service* (MMS) message contains pages with text and media objects (including pictures, animations, or sounds). You can send the multimedia message to other MMS-capable phones, and to email addresses.




Find it: Press  > **Create Message** > **New Multimedia Msg**


- 1 Press keypad keys to enter text on the page (for details about text entry, see page 22).

To insert a **picture, sound, or other object** on the page, press  > **Insert**. Select the file type and the file.


To insert **another page** in the message, enter text or objects on the current page and press  > **Insert** > **New Page**. You can enter more text and objects on the new page.

- 2 When you finish the message, press the **Send To** key.
- 3 Choose one or more people for **Send To**:


To select a **phonebook entry**, scroll to the entry and press the *center key* . Repeat to add other phonebook entries.

To **enter** a new number or email address, scroll to **[New Number]** or **[New Email Address]** and press the *center key* .

4 To **send** the message, press the **Send** key.

Before you send a message, press  to choose **Save to Drafts**, **Abort Message**, or open **Message Options** (such as message **Subject** or **CC** addresses).

receive a multimedia message

When you receive a multimedia message or letter, your phone plays an alert and the display shows **New Message** with a message indicator such as .



Press the **Read** key to open the message.


If a multimedia message contains media objects:


- Photos, pictures, and animations show as you read the message.
- A sound file plays when its slide shows. Use the volume keys to adjust the sound volume.

Note: In a multimedia letter, you may have to scroll to an indicator in the text to play a sound file.

- Attached files are added to the end of the message. To open an attachment, scroll to the file indicator/filename and press the **View** key (image), **Play** key (sound), or **Open** key (phonebook vCard, datebook vCalendar entry, or unknown file type).

cable connections

 Your phone has a mini-USB port so you can connect it to a computer to transfer data.



You can use data cables and supporting software on your computer to:

- Synchronize phonebook and datebook information between your phone and a computer or hand-held device.
- Use your phone as a modem to connect to the Internet.
- Use your phone to send and receive data calls from your computer or handheld device.


Note: Motorola Original USB data cables and supporting software are sold separately. Check your computer or hand-held device to determine the type of cable you need. To **transfer data** between your phone and computer, you must install the software included with the Motorola Original data kit. See the data kit user's guide for more information. To make **data and fax calls** through a connected computer, see page 56.




basics



See page 1 for a basic phone diagram.

display


The *home screen* shows when you turn on the phone. To dial a number from the home screen, press number keys and .

Note: Your home screen may look different from the one below, depending on your service provider.



The *Menu Indicator*  shows that you can press  to open the menu. *Soft Key Labels* show the current soft key functions. For soft key locations, see page 1.

Status indicators can show at the top of the home screen:



1 Signal Strength Indicator – Vertical bars show the strength of the network connection. You can't make or receive calls when or shows.

2 GPRS Indicator – Shows when your phone is using a high-speed *General Packet Radio Service* (GPRS) network connection. Indicators show PDP context active or packet data available .

3 Data Indicator – Shows connection status.

= secure packet data transfer

= unsecure packet data transfer

= secure application connection

= unsecure application connection

= secure *Circuit Switch Data* (CSD) call

= unsecure CSD call

- 4 Roam Indicator** – Shows when your phone is seeking or using a network outside your home network. Indicators can include:





 = 2G home

 = 2G roam

 = 2.5G home

 = 2.5G roam

- 5 Active Line Indicator** – Shows  to indicate an active call, or  to indicate when call forwarding is on. Indicators for dual-line-enabled SIM cards can include:



 = line 1 active

 = line 1 active, call forward on

 = line 2 active


 = line 2 active, call forward on

- 6 Messaging Presence Indicator** – Shows when Instant Messaging (IM) is active. Indicators can include:





 = IM active


 = available for IM

 = busy

 = invisible to IM


 = available for phone calls

 = offline

When a Java™ application is active,  can show here.

- 7 Message Indicator** – Shows when you receive a new message. Indicators can include:



 = text message

 = voicemail message

 = voicemail & text message

 = IM message

 = active chat session

8 Ring Style Indicator – Shows the ring style setting.

📞🔊 = loud ring

📞🔊🔊 = vibrate then ring


📞🔊🔊🔊 = soft ring


📞🔊🔊🔊🔊 = silent

📞🔊🔊🔊🔊🔊 = vibrate











9 Battery Level Indicator – Vertical bars show the battery charge level. Recharge the battery when your phone shows **Low Battery**.

menus

From the home screen, press  to enter the main menu.




The following menu icons may be available, depending on your service provider and service subscription options.

| menu features | |
|--|--|
|  Phonebook |  Web Access |
|  Recent Calls |  Multimedia |
|  Messages |  IM |
|  Tools |  Settings |
|  Games & Apps |  Chat |

Note: Your *Instant Messaging (IM)* menu icon may be different from the icon in the table, depending on your service provider.

Some features require you to select an option from a list:



- Scroll up or down to scroll to the option you want.
- In a numbered list, press a number key to highlight an option.

- In an alphabetized list, press a key repeatedly to cycle through its letters and highlight the closest matching list option.
- When an option has a list of possible settings, scroll left or right to select the setting.
- When an option has a list of possible numeric values, press a number key to set the value.


text entry

Some features let you enter text.

For indicator descriptions, see following section.

Flashing cursor indicates insertion point.





Press  to open sub-menu.

After you enter text, press the **Send To** key to enter recipients.



Press the **Cancel** key to exit without making changes.

Press  in a text entry view to select an entry mode:

entry modes


 or **1** Your **Primary** text entry mode can be set to any iTAP®  or tap **1** mode.


entry modes

 or **z** Your **Secondary** text entry mode can be set to any iTAP  or tap **z** mode, or set to **None** if you don't want a secondary entry mode.





12 **Numeric** mode enters numbers only.

@ **Symbol** mode enters symbols only.

To set your primary and secondary text entry modes, press  > **Entry Setup** in a text entry view and select **Primary Setup** or **Secondary Setup**.


Tip: WANT TO SHOUT YOUR MESSAGE? Press  in a text entry view to change text case to all capital letters (**AB**), next letter capital (**Ab**), or no capitals (**ab**).

iTAP® mode

Press  in a text entry view to switch to iTAP mode. If you don't see  or , press  > **Entry Setup** to set iTAP mode as your primary or secondary text entry mode.

iTAP mode lets you enter words using one keypress per letter. The iTAP software combines your keypresses into common words, and predicts each word as you enter it.

For example, if you press **7 7 6 4**, your display shows:



- If you want a different word (such as **Progress**), continue pressing keypad keys to enter the remaining letters.
- To enter numbers quickly, press and hold a number key to temporarily switch to numeric mode. Press the number keys to enter the numbers you want. Enter a space to change back to iTAP mode.
- Press **1** to enter punctuation or other characters.


tap mode

Press **#** in a text entry view to switch to tap mode. If you don't see **Ab 1** or **Ab 2**, press **☰** > **Entry Setup** to set tap mode as your primary or secondary text entry mode.

To enter text in tap mode, press a keypad key repeatedly to cycle through the letters and number on the key. Repeat this step to enter each letter.

For example, if you press **8** one time, your display shows:

Character displays at insertion point.




After 2 seconds, character is accepted and cursor moves to next position.

Press the **Delete** key to delete character to left of insertion point.




After you enter text, press the **Send To** key to enter recipients.

When you enter three or more characters in a row, your phone may guess the rest of the word. For example, if you enter **prog** your display might show:


Character displays at insertion point.




Press  right to accept **Program**, or press  to reject it and enter a space after **Prog**.

- The first character of every sentence is capitalized. If necessary, press  down to change the character to lowercase before the cursor moves to the next position.
- Press  to move the flashing cursor to enter or edit message text.
- If you don't want to save your text or text edits, press  to exit without saving.
- *Tap extended* mode cycles through additional special characters and symbols as you repeatedly press a keypad key.

numeric mode

Press  in a text entry view until you see **12**. Press the number keys to enter the numbers you want.


symbol mode

Press **#** in a text entry view until you see **@**. Press a keypad key to show its symbols at the bottom of the display. Scroll to the symbol you want, then press the *center key* .

volume

Press the volume keys to:



- turn off an incoming call alert
- change the earpiece volume during calls
- change the ringer volume from the home screen




Tip: Sometimes silence really is golden. That's why you can quickly set your ringer to **Vibrate** or **Silent** by holding the down volume key in the home screen.

To change your ringer volume when your phone is closed, see page 28.

navigation key

Press the *navigation key*  up, down, left, or right to scroll to items in the display. When you scroll to something, press the *center key*  to select it.



external display

When your phone is closed, the external display shows the time and indicates phone status, incoming calls, and other events. For a list of phone status indicators, see page 18.

handsfree speaker

You can use your phone's handsfree speaker to make calls without holding the phone to your ear.

During a call, press the **Speaker** key to turn the handsfree speaker on. Your display shows **Spkrphone On** until you turn it off or end the call.


Note: The handsfree speaker won't work when your phone is connected to a handsfree car kit or headset.

codes & passwords

Your phone's 4-digit **unlock code** is originally set to **1234**. The 6-digit **security code** is originally set to **000000**. If your service provider didn't change these codes, you should change them:

Find it: Press  >  **Settings** > **Security** > **New Passwords**



You can also change your **SIM PIN** password.



If you forget your unlock code: At the **Enter Unlock Code** prompt, try entering 1234 or the last four digits of your phone number. If that doesn't work, press  and enter your 6-digit security code instead.

If you forget other codes: If you forget your security code, SIM PIN code, or PIN2 code, contact your service provider.

lock & unlock phone

You can lock your phone to keep others from using it. To lock or unlock your phone, you need the 4-digit unlock code.

To **manually lock** your phone: Press  >  **Settings** > **Security** > **Phone Lock** > **Lock Now**.

To **automatically lock** your phone whenever you turn it off: Press  >  **Settings** > **Security** > **Phone Lock** > **Automatic Lock** > **On**.

Note: You can make emergency calls on a locked phone (see page 37). A locked phone still rings or vibrates for incoming calls or messages, **but you need to unlock it to answer**.

customize

ring style

Each ring style profile uses a different set of sounds or vibrations for incoming calls and other events. Here are the profiles you can choose:

 Loud

 Vibrate

 Silent

 Soft

 Vibe then Ring

The ring style profile's indicator shows at the top of your home screen. To choose your profile:

Find it: Press  >  Ring Styles > **Style:** *style name*


Shortcut: In the **home screen**, press the volume keys up or down to quickly change your ring style profile. With your **phone closed**, press a volume key to see your ring style profile, press the smart key to change it, then press a volume key to store the change.

change alerts in a ring style

You can change the alerts for incoming calls and other events. Your changes are saved in the current ring style profile.

Find it: Press  >  Ring Styles > *style Detail*

Note: *Style* represents the current ring style. You can't set an alert for the **Silent** ring style setting.

- 1 Scroll to **Calls** (or **Line 1** or **Line 2** for dual-line phones), then press the **Change** key to change it.
- 2 Scroll to the alert you want, then press the *center key* .
- 3 Press the **Back** key to save the alert setting.

Tip: If you want a ring that sets you apart, you can use an MP3 sound file. To download files, see page 60.

ring & event lights

Your phone has a light just below the external display that can pulse for incoming calls or messages, or while you charge your battery.



To set the light for your **incoming calls**, press  >  **Ring Styles** > **Ring Lights**.

You can also turn the ring light on or off for calls from phonebook entries in a **Category** (see page 46).

To set the light for your **incoming messages and battery charging**, press  >  **Ring Styles** > **Event Lights**.

time & date

Your phone needs the time and date for the datebook.

To **synchronize** the time and date with the network: Press  >  **Settings** > **Initial Setup** > **Time and Date** > **Autoupdate** > **On**.




To **manually** set the time and date, turn off **Autoupdate**, then:
Press  >  **Settings** > **Initial Setup** > **Time and Date** > *time* or *date*.

To choose an **analog or digital** clock for your home screen, press  >  **Settings** > **Personalize** > **Home Screen** > **Display** > **Clock**.

wallpaper

Set a photo, picture, or animation as a wallpaper (background) image in your home screen.

Find it: Press  >  **Settings** > **Personalize** > **Wallpaper**


| options | |
|----------------|---|
| Picture | Press  up or down to select a picture, or select None for no wallpaper. |
| Layout | Select Center to center the image in the display, Tile to repeat the image across the display, or Fit-to-screen to stretch the image across the display. |

screen saver



Set a photo, picture, or animation as a screen saver. The screen saver shows when the flip is open and no activity is detected for a specified time.

Tip: This feature helps save your screen, but not your battery. To extend battery life, turn off the screen saver.

Find it: Press  >  **Settings** > **Personalize** > **Screen Saver**

| options | |
|----------------|---|
| Picture | Press  up or down to select a picture or animation, or select None for no screen saver. |
| Delay | Select the length of inactivity before the screen saver shows. |

display appearance

To choose the **colors** that your phone uses for indicators, highlights, and soft key labels: Press  >  **Settings** > **Personalize** > **Color Style**.

To save battery life, your keypad **backlight** turns off when you're not using your phone. The backlight turns back on when you open the flip or press any key. To set how long your phone waits before the backlight turns off:

Press  >  **Settings** > **Initial Setup** > **Backlight**.

Note: To turn the backlight on or off for Java™ applications, press  >  **Settings** > **Java Settings** > **App Backlight**.

To save battery life, the **display** can turn off when you're not using your phone. The display turns back on when you open the flip or press any key. To set how long your phone waits before the display turns off:

Press  >  **Settings** > **Initial Setup** > **Display Timeout**.

answer options

You can use different ways to answer an incoming call. To turn on or turn off an answer option:

Find it: Press  >  **Settings** > **In-Call Setup** > **Answer Options**

| options | |
|-----------------------|-----------------------------|
| Multi-Key | Answer by pressing any key. |
| Open to Answer | Answer by opening the flip. |

calls


To make and answer calls, see page 11.

turn off a call alert

You can press the volume keys to turn off a call alert before answering the call.




recent calls


Your phone keeps lists of incoming and outgoing calls, even for calls that didn't connect. The most recent calls are listed first. The oldest calls are deleted as new calls are added.

Shortcut: Press  from the home screen to see a list of recent calls.



Find it: Press  >  **Recent Calls** > **Received Calls** or **Dialed Calls**


Scroll to a call. A ✓ next to a call means the call connected.

- To call the number, press .
- To see call details (like time and date), press the *center key* .
- To see the **Last Calls Menu**, press . This menu can include:

| options | |
|------------------------|--|
| Store | Create a phonebook entry with the number in the No. field. Store does not appear if the number is already stored. |
| Delete | Delete the entry. |
| Delete All | Delete all entries in the list. |
| Hide ID/Show ID | Hide or show your caller ID for the next call. |
| Send Message | Open a new text message with the number in the To field. |
| Add Digits | Add digits after the number. |
| Attach Number | Attach a number from the phonebook or recent calls lists. |
| Send Tones | Send the number to the network as DTMF tones. This option shows only during a call. |
| Talk then Fax | Talk and then send a fax in the same call (see page 56).  |

redial

- 1 Press  from the home screen to see a list of recent calls.
- 2 Scroll to the entry you want to call, then press .


If you hear a **busy signal** and you see **Call Failed, Number Busy**, you can press  or the **Retry** key to redial the number. When the call goes through, your phone



rings or vibrates one time, shows **Redial Successful**, and connects the call.

return a call

Your phone keeps a record of your unanswered calls, and shows **X Missed Calls**, where **X** is the number of missed calls.

- 1 Press the **View** key to see the received calls list.
- 2 Scroll to the call you want to return, then press .

caller ID

Calling line identification (caller ID) shows the phone number for an incoming call in your external and internal displays.



Your phone shows the caller's name and picture when they're stored in your phonebook, or **Incoming Call** when caller ID information isn't available.

You can set your phone to play a different ringer ID for an entry stored in your phonebook (see page 45).

To show or hide **your phone number** from the next person you call, enter the phone number and press


 > **Hide ID/Show ID**.

emergency calls

Your service provider programs one or more emergency phone numbers, such as 911 or 112, that you can call under

any circumstances, even when your phone is locked or the SIM card is not inserted.

Note: Emergency numbers vary by country. Your phone's preprogrammed emergency number(s) may not work in all locations, and sometimes an emergency call cannot be placed due to network, environmental, or interference issues.


- 1 Press the keypad keys to dial the emergency number.
- 2 Press  to call the emergency number.

voicemail


Your network stores the voicemail messages you receive. To listen to your messages, call your voicemail number.



Note: Your service provider may include additional information about using this feature.

When you **receive** a voicemail message, your phone shows the voicemail message indicator  and **New Voicemail**. Press the **Call** key to listen to the message.

To **check** voicemail messages:

Find it: Press  > **Voicemail**

Your phone may prompt you to store your voicemail phone number. If you don't know your voicemail number, contact your service provider.

Note: You can't store a **p** (pause), **w** (wait), or **n** (number) character in this number. If you want to store a voicemail number with these characters, create a phonebook entry for it. Then, you can use the entry to call your voicemail.

other features

advanced calling

features

1-touch dial




To call phonebook entries 1 through 9, press and hold the single-digit speed dial number for one second.

You can set 1-touch dial to call the entries in your phone's memory phonebook, your SIM card's phonebook, or your Fixed Dial list: Press



 >  **Settings** > **Initial Setup** > **1-Touch Dial**
> **Phone, SIM, or Fixed Dial**

To add a new phonebook entry, see page 11. To edit the **Speed No.** for a phonebook entry, press


 >  **Phonebook**, scroll to the entry, and press  > **Edit**.

features



speed dial

Speed dial a phonebook entry:



Enter the speed dial number, press , then press .

To add a phonebook entry, see page 11.

Tip: If you forget Aunt Mildred's speed dial number, press  >  **Phonebook**, scroll to her entry, and press the *center key* .

attach a phone number

Dial an area code or prefix for a phonebook number, then:





 > **Attach Number**

notepad


The last number you entered is stored in the *notepad*. You can use the notepad to “jot down” a number during a call for later use. To see the notepad:

Press  >  **Recent Calls** > **Notepad**


- To call the number, press .
- To create a phonebook entry with the number in the **No.** field, press the **Store** key.
- To open the **Dialing Menu** to attach a number or insert a special character, press .

features


international calls

If your phone service includes international dialing, press and hold  to insert your local international access code (indicated by +). Then, press the keypad keys to dial the country code and phone number.


hold a call

Press  > **Hold** to put all active calls on hold.


mute a call



Press  > **Mute** to put all active calls on mute.

call waiting

When you're on a call, you'll hear an alert if you receive a second call. 


Press  to answer the new call.



















- To switch between calls, press the **Switch** key.
- To connect the two calls, press the **Link** key.
- To end the call on hold, press  > **End Call On Hold**.

To turn the call waiting feature on or off, press  >  **Settings** > **In-Call Setup** > **Call Waiting** > **On** or **Off**

conference call

During a call:

Dial next number, press , press the **Link** key.

| features | |
|--------------------------|--|
| transfer a call | <p>During a call:</p> <p> > Transfer, dial transfer number, press </p>  |
| call forwarding | <p>Set up or cancel call forwarding:</p> <p> >  Settings > Call Forward</p>  |
| restrict calls | <p>Restrict outgoing or incoming calls:</p> <p> >  Settings > Security > Restrict Calls</p>  |
| call barring | <p>Restrict outgoing or incoming calls:</p> <p> >  Settings > Security > Call Barring</p>  |
| TTY calls | <p>Set up your phone for use with an optional TTY device:</p> <p> >  Settings > Initial Setup > TTY Setup</p>  |
| change phone line | <p>If you have a dual-line-enabled SIM card, you can change your line to make and receive calls from your other phone number.</p> <p> >  Settings > Phone Status > Active Line</p> <p>The active line indicator shows the active phone line (see page 19).</p>  |



features

fixed dial

When you turn on fixed dialing, you can call only numbers stored in the fixed dial list.



Turn fixed dialing on or off:

 >  **Settings** > **Security** > **Fixed Dial**

Use the fixed dial list:

 >  **Tools** > **Dialing Services** > **Fixed Dial**

quick dial



Dial preprogrammed phone numbers:




 >  **Tools** > **Dialing Services** > **Quick Dial**




DTMF tones

Activate DTMF tones:

 >  **Settings** > **Initial Setup** > **DTMF**

To send DTMF tones during a call, just press number keys or scroll to a number in the phonebook or recent calls lists and press  > **Send Tones**.

phonebook

| features | |
|--|---|
| edit or delete a phonebook entry | <p>Edit a number stored in the phonebook:  >  Phonebook, scroll to the phonebook entry, and press . You can select Edit, Delete, or other options.</p> <p>Shortcut: In the phonebook, press keypad keys to enter the first letters of an entry name, then press the Search key to jump to the entry.</p> |
| record voice name for a phonebook entry | <p>When creating a phonebook entry, scroll to Voice Name and press the Record key. Press the Record key again and say the entry's name (within 2 seconds). When prompted, press the Record key and repeat the name.</p> <p>Note: The Voice Name option isn't available in entries stored on the SIM card.</p> |



features

voice dial a phonebook entry

Voice dial a number stored in the phonebook:




 >  **Tools** > **Dialing Services** > **Voice Dial**

When prompted, say the entry's voice name (within 2 seconds).

Tip: If you use **Voice Dial** a lot, you can create a shortcut to it. Scroll to **Voice Dial**, then press and hold . To use the shortcut, press  and the shortcut key number.



set ringer ID for a phonebook entry

Assign a ring alert (ringer ID) to an entry:

 >  **Phonebook** > *entry*, then press  > **Edit** > **Ringer ID** > *ringer name*




Note: The **Ringer ID** option isn't available in entries stored on the SIM card.

Activate ringer IDs:














 >  **Ring Styles** > *style* **Detail** > **Ringer IDs**

set picture ID for a phonebook entry

Assign a photo or picture to show when you receive a call from an entry:

 >  **Phonebook** > *entry*, then press  > **Edit** > **Picture** > *picture name*

Note: The **Picture** option isn't available in entries stored on the SIM card.

| features | |
|--|---|
| set picture ID view for phonebook | <p>Show entries as a text list, or with picture caller ID photos:</p> <p> >  Phonebook, then press</p> <p> > Setup > View by > <i>view name</i></p> |
| set category for a phonebook entry | <p> >  Phonebook > <i>entry</i>, then press</p> <p> > Edit > Category > <i>category name</i></p> <p>Note: The Category option isn't available in entries stored on the SIM card.</p> |
| set category view for phonebook | <p> >  Phonebook, then press</p> <p> > Categories > <i>category name</i></p> <p>You can show All entries, entries in a predefined category (Business, Personal, General, VIPs), or entries in a category you create.</p> |
| set light ID for phonebook category | <p>Turn on or off the ring light for calls from entries in a category:</p> <p> >  Phonebook  > Categories, scroll to the category, press  > Edit > Light ID</p> <p>For more about ring lights, see page 31.</p> <p>Note: The Category option isn't available in entries stored on the SIM card.</p> |


features

set primary number or address for a phonbook entry

Set the primary number for an entry with multiple numbers:

 >  **Phonebook**, scroll to the entry, press  > **Set Primary** > *number or address*

Note: The **Set Primary** option isn't available in entries stored on the SIM card.

Tip: In **Primary** number view mode, you can still peek at other numbers stored for the same name. Scroll to the name and press  left or right to see the other numbers.







create group mailing list

You can put several phonebook entries in a group mailing list, then send a message to the list. To create a list:

 >  **Phonebook**, then press  > **New** > **Mailing List**





You can select the list name as an address for multimedia messages.






















Note: A **Mailing List** cannot include entries stored on the SIM card.



| features | |
|---------------------------------|---|
| sort phonebook list | <p>Set the order in which entries are listed:</p> <p> >  Phonebook, then press  > Setup > Sort by > <i>sort order</i></p> <p>You can sort the phonebook list by Name, Speed No., Voice Name, or Email. When sorting by name, you can see All numbers or just the Primary number for each name.</p> |
| copy one phonebook entry | <p>Copy an entry from the phone to the SIM card, or from the SIM card to the phone:</p> <p> >  Phonebook, scroll to the entry, press  > Copy > Entries > To</p> |

messages











For basic multimedia message features, see page 14.

















| features | |
|---------------------------|---|
| send text message | <p> > Create Message > New Short Msg </p> |
| send voice message | <p> > Create Message > New Voice Msg </p> <p>To record the voice message, press the Record key, speak, then press the Stop key. Your phone inserts the voice recording into a message and lets you enter email addresses or phone numbers to receive the message.</p> |

| features | |
|---|---|
| use a multimedia template | <p>Open a multimedia message with preloaded animations: </p> <p> > Create Message > MMS Templates</p> |
| read and manage messages | <p> > Message Inbox </p> <p>Icons next to each message indicate if it is read  or unread . Icons can also indicate if the message is locked , urgent , low priority , or has an attachment .</p> <p>To see message options like Reply, Forward, Lock, or Delete, scroll to a message and press .</p> |
| store message objects | <p>Go to a multimedia message page, or scroll to an object in a message, then: </p> <p> > Store</p> |
| store text messages on your SIM card | <p>To store incoming text messages on your SIM card, press: </p> <p> >  Messages, then press</p> <p> > Message Setup > Text Msg Setup > Store To > SIM</p> <p>  > Inbox Setup > Text Msg Setup > Store To > SIM</p> |
| browser messages | <p>Read messages received by your micro-browser: </p> <p> > Browser Msgs</p> |








| features | | |
|----------------------|--|---|
| info services | Read subscription-based information services messages:  > Info Services |  |

instant messaging











| features | | |
|---------------------------------|---|---|
| log in |  >  IM > Log In |  |
| add contacts | After you log in: Select Contact List > Add Contact and enter the contact's IM ID and nickname. |  |
| find others online | After you log in: Select Contact List to see a list of others online. |  |
| start conversation | From your Contact List , scroll to a name in Online Contacts , press the Send IM key. |  |
| open active conversation | From your Contact List , scroll to a name in Conversations , press the View key. |  |
| end conversation | From the conversation view:  > End Conversation |  |
| log out | Select Log Out from the IM Online menu. |  |













| features | |
|-------------------------------------|--|
| create or change IM accounts |  >  IM > IM Account  <p>Select an IM account, or select New to create a new IM account.</p> |
| log in automatically |  >  IM > Offline Settings  <p>Turn on Auto-Login to start the IM login whenever you select  > IM. Turn on Power-On Login to start the IM login whenever you turn on your phone.</p> |
| hide your online status |  <p>When you log in, other users can see you are Online. To change your status in IM, press  > My Status > Away or Invisible.</p> |
| block contacts |  <p>To block instant messages from a contact, scroll to the contact in the Contact List and press  > Block Contact. You must be online to block a contact. Blocked contacts will not appear in your Contact List.</p> |
| set alerts for contacts |  <p>When a special contact comes online, your phone can ring or vibrate. Scroll to the contact in the Contact List and press  > Set Online Alert.</p> |
| set IM ring style |  <p>Select a ring or vibration for new IM messages and contact alerts.</p> <p> >  Ring Styles > <i>style</i> Detail > IM</p> |





chat

| features | |
|-----------------------------|---|
| start chat |  >  Tools > Chat, then press  > New Chat  |
| receive chat request | Press the Accept key or the Ignore key.  |
| end chat | During a chat session:  > End Chat  |


personalizing

| features | |
|----------------------------|---|
| language | Set menu language:  >  Settings > Initial Setup > Language |
| scroll | Set the scroll bar to stop or wrap around in menu lists:  >  Settings > Initial Setup > Scroll |
| activate ringer IDs | Activate ringer IDs assigned to phonebook entries and categories:  >  Ring Styles > <i>style</i> Detail > Ringer IDs |
| ring volume | Press  >  Ring Styles > <i>style</i> Detail > Ring Volume |
| keypad volume | Press  >  Ring Styles > <i>style</i> Detail > Key Volume |


| features | |
|-----------------------------|---|
| reminders | <p>Set reminder alerts for messages that you receive:</p> <p>Press  >  Ring Styles > <i>style</i> Detail > Reminders</p> |
| menu view | <p>Show the main menu as graphic icons or as a text-based list:</p> <p> >  Settings > Personalize > Main Menu > View</p> |
| main menu | <p>Reorder your phone's main menu:</p> <p> >  Settings > Personalize > Main Menu > Reorder</p> |
| show/hide menu icons | <p>Show or hide menu feature icons in the home screen:</p> <p> >  Settings > Personalize > Home Screen > Home Keys > Icons</p> |
| change home keys | <p>Change the features for the soft keys and navigation key in the home screen:</p> <p> >  Settings > Personalize > Home Screen > Home Keys</p> |
| shortcuts | <p>Create a shortcut to a menu item:</p> <p>Scroll to the menu item, then press and hold .</p> <p>Use a shortcut:</p> <p>Press , then press the shortcut number.</p> |

| features | |
|---------------------|---|
| master reset | Reset all options except unlock code, security code, and lifetime timer:  >  Settings > Initial Setup > Master Reset |
| master clear | Caution: Master clear erases all information you have entered (including phonebook and datebook entries) and content you have downloaded (including photos and sounds) stored in your phone's memory. After you erase the information, you can't recover it.  >  Settings > Initial Setup > Master Clear |

call times & costs

Network connection time is the elapsed time from the moment you connect to your service provider's network to the moment you end the call by pressing . This time includes busy signals and ringing.

The amount of network connection time you track on your resettable timer may not equal the amount of time for which you are billed by your service provider. For billing information, contact your service provider.







| features | |
|-------------------|--|
| call times | Show call timers:  >  Recent Calls > Call Times  |

| features | | |
|----------------------|---|--|
| in-call timer | Show time or cost information during a call: | |
| | > Settings > In-Call Setup > In-Call Timer | |
| call cost | Show call cost trackers: | |
| | > Recent Calls > Call Cost | |

handsfree






Note: The use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products.

| features | | |
|--|--|--|
| speakerphone | Activate the speakerphone during a call: Press the Speaker key (if available, or > Spkrphone On). | |
| auto answer (car kit or headset) | Automatically answer calls when connected to a car kit or headset: | |
| | > Settings > Car Settings or Headset > Auto Answer | |
| voice dial (headset) | Enable voice dial with headset send/end key: | |
| | > Settings > Headset > Voice Dial | |
| auto handsfree (car kit) | Automatically route calls to a car kit when connected: | |
| | > Settings > Car Settings > Auto Handsfree | |

| features | | |
|----------------------------------|--|---|
| power-off delay (car kit) | Set the phone to stay on for a specified time after the ignition is switched off: |  |
| |  >  Settings > Car Settings > Power-Off Delay | |
| charger time (car kit) | Charge the phone for a specified time after the ignition is switched off: |  |
| |  >  Settings > Car Settings > Charger Time | |

data & fax calls

To connect your phone with a USB cable, see page 16.



| features | | |
|----------------------------|---|---|
| send data or fax | Connect your phone to the device, then place the call through the device application. |  |
| receive data or fax | Connect your phone to the device, then answer the call through the device application. |  |
| talk then fax | Connect your phone to the device, enter fax number, press  > Talk then Fax , then press  to make the call. |  |



features

using sync

You can call an Internet server and synchronize your phonebook and datebook entries with the server.



To **set up** an Internet sync partner, press  >  **Settings** > **Sync** > **[New Entry]**. Enter the server details, including **Server URL** (you can omit **http://**) and **Data Path** (the folder below the URL where your data is stored).

To **synchronize files** with a partner you set up, select the partner from the list in  >  **Settings** > **Sync**.

network

features

network settings

See network information and adjust network settings:

















 >  **Settings** > **Network**

personal organizer








features

set alarm

 >  **Tools** > **Alarm Clock**


| features | |
|-------------------------------|--|
| turn off alarm | When an alarm happens: To turn off the alarm, press the Disable key or  . To set an 8 minute delay, press the Snooze key. |
| add new datebook event |  >  Tools > Datebook , scroll to the day, press  , press  > New |
| see datebook event | See or edit event details:  >  Tools > Datebook , scroll to the day, press  , press the View key |
| event reminder | When an event reminder happens: To see reminder details, press the View key. To close the reminder, press the Exit key. |
| calculator |  >  Tools > Calculator |
| currency converter |  >  Tools > Calculator , then press  > Exchange Rate Enter exchange rate, press the OK key, enter amount, and press  > Convert Currency . |

security

| features | |
|----------------------------|---|
| SIM PIN | <p>Caution: If you enter an incorrect PIN code 3 times in a row, your SIM card is disabled and your display shows SIM Blocked.</p> <p>Lock or unlock the SIM card:</p> <p> >  Settings > Security > SIM PIN</p> |
| lock feature | <p> >  Settings > Security > Lock Application</p> |
| manage certificates | <p>Enable or disable Internet access certificates stored on your phone: </p> <p> >  Settings > Security > Certificate Mgmt</p> <p>Certificates are used to verify the identity and security of Web sites when you download files or share information.</p> |

fun & games

Note: A lock (🔒) icon next to a picture, sound, or other object means that you cannot send or copy it.

| features | |
|---|--|
| view, delete, or manage pictures | <p>Manage photos, pictures, and animations: </p> <p> >  Multimedia > Pictures</p> |


| | |
|--|--|
| features | |
| view, delete, or manage video clips |  >  Multimedia > Videos |
| hear, delete, or manage sounds | Manage ring tones and music that you have downloaded or composed:  >  Multimedia > Sounds |
| create ring tones | Create ring tones that you can use with your phone:  >  Multimedia > Sounds > [New iMelody] |
| start micro-browser | Just press  .  |
| download objects from Web page | Download a picture, sound, or other object from a Web page:  Press  , go to the page that links to the file, scroll to the link, and select it. Note: Normal airtime and/or carrier usage charges apply. |
| Web sessions | A <i>Web Session</i> stores settings that your phone uses to access the Internet. To select or create a Web session:   >  Web Access > Web Sessions |

features

download game or application

You can download a Java™ game or application the same way you download pictures or other objects:






Press , go to the page that links to the file, scroll to the link, and select it.

Note: Normal airtime and/or carrier usage charges apply.

start game or application

Start a Java™ game or application:



 >  **Games & Apps**, scroll to the game or application, press the *center key* .

service and repairs

If you have questions or need assistance, we're here to help.

Go to www.motorola.com/consumer/support, where you can select from a number of customer care options. You can also contact the Motorola Customer Support Center at 1-800-331-6456 (United States), 1-888-390-6456 (TTY/TDD United States for hearing impaired), or 1-800-461-4575 (Canada).

Specific Absorption Rate Data

This model wireless phone meets the government's requirements for exposure to radio waves.

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission (FCC) of the U.S. Government and by the Canadian regulatory authorities. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age or health.

The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC and by the Canadian regulatory authorities is 1.6 W/kg.¹ Tests for SAR are conducted using standard operating positions accepted by the FCC and by Industry Canada with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station, the lower the power output.

Before a phone model is available for sale to the public in the U.S. and Canada, it must be tested and certified to the FCC and Industry Canada that it does not exceed the limit established by each government for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) reported to the FCC and available for review by Industry Canada. The highest SAR value for this model phone when tested

for use at the ear is 1.39 W/kg , and when worn on the body, as described in this user guide, is 0.43 W/kg. The SAR value for this product in its data transmission mode (body-worn use) is 0.65 W/kg. (Body-worn measurements differ among phone models, depending upon available accessories and regulatory requirements).²

While there may be differences between the SAR levels of various phones and at various positions, they all meet the governmental requirements for safe exposure. Please note that improvements to this product model could cause differences in the SAR value for later products; in all cases, products are designed to be within the guidelines.

Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications & Internet Association (CTIA) Web site:

<http://www.phonefacts.net>

or the Canadian Wireless Telecommunications Association (CWTA) Web site:

<http://www.cwta.ca>

1. In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.
2. The SAR information includes the Motorola testing protocol, assessment procedure, and measurement uncertainty range for this product.

index

A

- accessories 5, 55
- accessory connector port 1
- active line indicator 18
- active line, changing 42
- alarm clock 57, 58
- alert
 - lights 30
 - set 26, 29
 - turn off 26, 34
- animation 59
- answer a call 9, 32
- attach a number 35, 40

B

- backlight 32
- battery 6, 7
- battery indicator 19
- battery life, extending 8,
31, 32
- browser messages 49
- browser. See micro-browser

C

- cables 15
- calculator 58
- call

- answer 9, 32
 - end 9
 - make 9
- call barring 42
- call forward indicator 18
- call forwarding 42
- call timers 54, 55
- call waiting 41
- caller ID 35, 36, 45
- car kit 55
- center key 1, 26
- center select key 5
- certificate management 59
- chat 52
- clock 30
- codes 27, 28
- color 32
- conference call 41
- costs, tracking 55

D

- data call 56
- data indicator 17
- date, setting 30
- datebook 58
- dial a phone number 9, 43
- diald calls 34

display 16, 32
download media objects
49, 60
drafts folder 14
DTMF tones 35, 43

E

earpiece volume 26
emergency number 36
end a call 9
end key 1, 9
Enter Unlock Code
message 27
event lights 30
external display 27

F

fax call 35, 56
fixed dial 43
flip 9, 33
forward calls 42

G

games 61
GPRS indicator 17
group mailing list 47

H

handsfree speaker 27
headset 55

headset jack 1
hold a call 41
home screen 16, 53

I

IM 50
IM indicators 18
in-call indicator 18
Incoming Call message 36
information services 50
instant messaging. See IM
international access code
41
iTAP text entry mode 22

J

Java applications 61
Java indicator 18

K

keypad 33, 52

L

language 52
light 30
light ID 46
lock
application 59
phone 28
SIM card 59

Low Battery message 19

M

make a call 9
master clear 54
master reset 54
menu 5, 19, 52, 53
menu icons 20, 53
menu indicator 16
message 48, 49
message indicator 14, 18
message reminders 53
micro-browser 49, 60, 61
Missed Calls message 36
MMS, defined 13
MP3 sound files 30
multimedia message 13, 49
music 60
mute a call 41

N

navigation key 1, 5, 26
network settings 57
notepad 40
number. See phone number
numeric entry mode 25

O

1-touch dial 39
open to answer 33
optional accessory 5

optional feature 5

P

passwords. See codes
personalize 52
phone number 10, 42
phonebook 35, 39, 40, 44
photo 59
picture 59
picture ID 36, 45
PIN code 9, 27, 59
PIN2 code 27
power key 1, 9

Q

quick dial 43

R

received calls 34
recent calls 34
redial 35
reminders 53
restrict calls 42
return a call 36
ring lights 30
ring style indicator 19
ring style, setting 26, 29
ring tone 60
ringer ID 36, 45, 52
ringer volume 26, 52
roam indicator 18

S

- screen saver 31
- security code 27
- send key 1, 9
- shortcuts 53
- signal strength indicator 17
- SIM 49
- SIM Blocked message 9, 59
- SIM card 6, 9, 27, 59
- soft keys 1, 16, 53
- speakerphone 55
- speed dial 40
- store your number 10
- symbol entry mode 26
- synchronizing 57

T

- tap text entry mode 23
- telephone number. See phone number
- text entry 21
- text message 48, 49
- time, setting 30
- timers 54, 55
- transfer a call 42
- TTY device 42
- turn on/off 9

U

- unlock
 - application 59
 - phone 9, 27, 28
 - SIM card 59
- unlock code 27, 28
- USB cables 15

V

- video clip 60
- videos 12
- voice dial 45, 55
- voice message 48
- voice name, recording 44
- voicemail 37
- voicemail message indicator 18, 37
- volume 26, 52

W

- wallpaper 31
- Web pages 60
- Web sessions 60

Y

- your phone number 10
- U.S. patent Re. 34,976



MOTOROLA

***IMPORTANT SAFETY AND
LEGAL INFORMATION >***

Software Copyright Notice

The Motorola products described in this manual may include copyrighted Motorola and third-party software stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Motorola and third-party software providers certain exclusive rights for copyrighted software, such as the exclusive rights to distribute or reproduce the copyrighted software. Accordingly, any copyrighted software contained in the Motorola products may not be modified, reverse-engineered, distributed, or reproduced in any manner to the extent allowed by law. Furthermore, the purchase of the Motorola products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents, or patent applications of Motorola or any third-party software provider, except for the normal, non-exclusive, royalty-free license to use that arises by operation of law in the sale of a product.

Manual Number: 6809497A47-0

Contents

| | |
|--|-----------|
| Safety Information | 4 |
| Exposure To Radio Frequency (RF) Energy..... | 4 |
| Operational Precautions..... | 4 |
| RF Energy Interference/Compatibility..... | 5 |
| Driving Precautions..... | 7 |
| Operational Warnings..... | 7 |
| Choking Hazards..... | 9 |
| Glass Parts..... | 9 |
| Seizures/Blackouts..... | 9 |
| Repetitive Motion..... | 9 |
| Warranty | 11 |
| What Does this Warranty Cover?..... | 11 |
| Who Is Covered?..... | 14 |
| What Will Motorola Do?..... | 14 |
| How to Obtain Warranty Service or Other Information..... | 14 |
| What Other Limitations Are There?..... | 15 |
| Hearing Aid Compatibility | 17 |
| WHO Information | 19 |
| Product Registration | 19 |
| Export Law Assurances | 20 |
| Wireless: The New Recyclable | 20 |
| Smart Practices While Driving | 21 |

Safety and General Information

This section contains important information on the safe and efficient operation of your mobile device. Read this information before using your mobile device.*

Exposure To Radio Frequency (RF) Energy

Your mobile device contains a transmitter and receiver. When it is ON, it receives and transmits RF energy. When you communicate with your mobile device, the system handling your call controls the power level at which your mobile device transmits.

Your Motorola mobile device is designed to comply with local regulatory requirements in your country concerning exposure of human beings to RF energy.

Operational Precautions

For optimal mobile device performance and to be sure that human exposure to RF energy does not exceed the guidelines set forth in the relevant standards, always follow these instructions and precautions.

External Antenna Care

If your mobile device has an external antenna, use only a Motorola-supplied or approved replacement antenna. Use of unauthorized antennas, modifications, or attachments could damage the mobile device and/or may result in your device not complying with local regulatory requirements in your country.

* The information provided in this document supersedes the general safety information in user's guides published prior to September 1, 2005.

DO NOT hold the external antenna when the mobile device is IN USE. Holding the external antenna affects call quality and may cause the mobile device to operate at a higher power level than needed.

Product Operation

When placing or receiving a phone call, hold your mobile device just like you would a landline phone.

If you wear the mobile device on your body, always place the mobile device in a Motorola-supplied or approved clip, holder, holster, case, or body harness. If you do not use a body-worn accessory supplied or approved by Motorola, keep the mobile device and its antenna at least 2.5 centimeters (1 inch) from your body when transmitting.

When using any data feature of the mobile device, with or without an accessory cable, position the mobile device and its antenna at least 2.5 centimeters (1 inch) from your body.

Using accessories not supplied or approved by Motorola may cause your mobile device to exceed RF energy exposure guidelines. For a list of Motorola-supplied or approved accessories, visit our website at www.motorola.com.

RF Energy Interference/Compatibility

Nearly every electronic device is subject to RF energy interference from external sources if inadequately shielded, designed, or otherwise configured for RF energy compatibility. In some circumstances your mobile device may cause interference with other devices.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Follow Instructions to Avoid Interference Problems

Turn off your mobile device in any location where posted notices instruct you to do so. These locations include hospitals or health care facilities that may be using equipment that is sensitive to external RF energy.

In an aircraft, turn off your mobile device whenever instructed to do so by airline staff. If your mobile device offers an airplane mode or similar feature, consult airline staff about using it in flight.

Pacemakers

If you have a pacemaker, consult your physician before using this device.

Persons with pacemakers should observe the following precautions:

- ALWAYS keep the mobile device more than 20 centimeters (8 inches) from your pacemaker when the mobile device is turned ON.
- DO NOT carry the mobile device in the breast pocket.
- Use the ear opposite the pacemaker to minimize the potential for interference.
- Turn OFF the mobile device immediately if you have any reason to suspect that interference is taking place.

Hearing Aids

Some digital mobile devices may interfere with some hearing aids. In the event of such interference, you may want to consult your hearing aid manufacturer or physician to discuss alternatives.

Other Medical Devices

If you use any other personal medical device, consult your physician or the manufacturer of your device to determine if it is adequately shielded from RF energy.

Driving Precautions

Check the laws and regulations on the use of mobile devices in the area where you drive. Always obey them.

When using your mobile device while driving, please:

- Give full attention to driving and to the road. Using a mobile device may be distracting. Discontinue a call if you can't concentrate on driving.
- Use handsfree operation, if available.
- Pull off the road and park before making or answering a call if driving conditions so require.

Responsible driving practices can be found in the “Smart Practices While Driving” section at the end of this guide and/or at the Motorola website: www.motorola.com/callsmart.

Operational Warnings

Obey all posted signs when using mobile devices in public areas, such as health care facilities or blasting areas.

Automobile Air Bags

Do not place a mobile device in the air bag deployment area.

Potentially Explosive Atmospheres

Areas with potentially explosive atmospheres are often but not always posted, and can include fueling areas such as below decks on boats, fuel or chemical transfer or storage facilities, or areas where the air contains chemicals or particles, such as grain, dust, or metal powders.

When you are in such an area, turn off your mobile device, and do not remove, install, or charge batteries. In such areas, sparks can occur and cause an explosion or fire.

Damaged Products






If your mobile device or battery has been submerged in water, punctured, or subjected to a severe fall, do not use it until you take it to a Motorola Authorized Service Center. Do not attempt to dry it with an external heat source, such as a microwave oven.

Batteries and Chargers

If jewelry, keys, beaded chains, or other conductive materials touch exposed battery terminals, this could complete an electrical circuit (short circuit), become very hot, and could cause damage or injury. Be careful when handling a charged battery, particularly when placing it inside a pocket, purse, or other container with metal objects. **Use only Motorola Original™ batteries and chargers.**

Caution: To avoid risk of personal injury, do not dispose of your battery in a fire.

Your battery, charger, or mobile device may contain symbols, defined as follows:

| Symbol | Definition |
|---|--|
|  | Important safety information follows. |
|  | Do not dispose of your battery or mobile device in a fire. |
|  | Your battery or mobile device may require recycling in accordance with local laws. Contact your local regulatory authorities for more information. |
|  | Do not throw your battery or mobile device in the trash. |
|  | Your mobile device contains an internal lithium ion battery. |

Choking Hazards

Your mobile device or its accessories may include detachable parts, which may present a choking hazard to small children. Keep your mobile device and its accessories away from small children.

Glass Parts

Some parts of your mobile device may be made of glass. This glass could break if the product is dropped on a hard surface or receives a substantial impact. If glass breaks, do not touch or attempt to remove. Stop using your mobile device until the glass is replaced by a qualified service center.

Seizures/Blackouts

Some people may be susceptible to epileptic seizures or blackouts when exposed to flashing lights, such as when playing video games. These may occur even if a person has never had a previous seizure or blackout.

If you have experienced seizures or blackouts, or if you have a family history of such occurrences, please consult with your physician before playing video games or enabling a flashing-lights feature (if available) on your mobile device.

Discontinue use and consult a physician if any of the following symptoms occur: convulsion, eye or muscle twitching, loss of awareness, involuntary movements, or disorientation. It is always a good idea to hold the screen away from your eyes, leave the lights on in the room, take a 15-minute break every hour, and stop use if you are very tired.

Repetitive Motion

When you repetitively perform actions such as pressing keys or entering finger-written characters, you may experience occasional discomfort in your hands, arms, shoulders, neck, or other parts of your body. If you

continue to have discomfort during or after such use, stop use and see a physician.

Motorola Limited Warranty for the United States and Canada

What Does this Warranty Cover?

Subject to the exclusions contained below, Motorola, Inc. warrants its telephones, pagers, messaging devices, and consumer and professional two-way radios (excluding commercial, government or industrial radios) that operate via Family Radio Service or General Mobile Radio Service, Motorola-branded or certified accessories sold for use with these Products ("Accessories") and Motorola software contained on CD-ROMs or other tangible media and sold for use with these Products ("Software") to be free from defects in materials and workmanship under normal consumer usage for the period(s) outlined below. This limited warranty is a consumer's exclusive remedy, and applies as follows to new Motorola Products, Accessories and Software purchased by consumers in the United States or Canada, which are accompanied by this written warranty:

Products and Accessories

| Products Covered | Length of Coverage |
|--|---|
| Products and Accessories as defined above, unless otherwise provided for below. | One (1) year from the date of purchase by the first consumer purchaser of the product unless otherwise provided for below. |
| Decorative Accessories and Cases. Decorative covers, bezels, PhoneWrap™ covers and cases. | Limited lifetime warranty for the lifetime of ownership by the first consumer purchaser of the product. |

| Products Covered | Length of Coverage |
|---|--|
| Monaural Headsets. Ear buds and boom headsets that transmit mono sound through a wired connection. | Limited lifetime warranty for the lifetime of ownership by the first consumer purchaser of the product. |
| Consumer and Professional Two-Way Radio Accessories. | Ninety (90) days from the date of purchase by the first consumer purchaser of the product. |
| Products and Accessories that are Repaired or Replaced. | The balance of the original warranty or for ninety (90) days from the date returned to the consumer, whichever is longer. |

Exclusions

Normal Wear and Tear. Periodic maintenance, repair and replacement of parts due to normal wear and tear are excluded from coverage.

Batteries. Only batteries whose fully charged capacity falls below 80% of their rated capacity and batteries that leak are covered by this limited warranty.

Abuse & Misuse. Defects or damage that result from: (a) improper operation, storage, misuse or abuse, accident or neglect, such as physical damage (cracks, scratches, etc.) to the surface of the product resulting from misuse; (b) contact with liquid, water, rain, extreme humidity or heavy perspiration, sand, dirt or the like, extreme heat, or food; (c) use of the Products or Accessories for commercial purposes or subjecting the Product or Accessory to abnormal usage or conditions; or (d) other acts which are not the fault of Motorola, are excluded from coverage.

Use of Non-Motorola Products and Accessories. Defects or damage that result from the use of Non-Motorola branded or certified Products, Accessories, Software or other peripheral equipment are excluded from coverage.

Unauthorized Service or Modification. Defects or damages resulting from service, testing, adjustment, installation, maintenance, alteration, or modification in any way by someone other than Motorola, or its authorized service centers, are excluded from coverage.

Altered Products. Products or Accessories with (a) serial numbers or date tags that have been removed, altered or obliterated; (b) broken seals or that show evidence of tampering; (c) mismatched board serial numbers; or (d) nonconforming or non-Motorola housings, or parts, are excluded from coverage.

Communication Services. Defects, damages, or the failure of Products, Accessories or Software due to any communication service or signal you may subscribe to or use with the Products Accessories or Software is excluded from coverage.

Software

| Products Covered | Length of Coverage |
|--|--|
| Software. Applies only to physical defects in the media that embodies the copy of the software (e.g. CD-ROM, or floppy disk). | Ninety (90) days from the date of purchase. |

Exclusions

Software Embodied in Physical Media. No warranty is made that the software will meet your requirements or will work in combination with any hardware or software applications provided by third parties, that the operation of the software products will be uninterrupted or error free, or that all defects in the software products will be corrected.

Software NOT Embodied in Physical Media. Software that is not embodied in physical media (e.g. software that is downloaded from the internet), is provided "as is" and without warranty.

Who Is Covered?

This warranty extends only to the first consumer purchaser, and is not transferable.

What Will Motorola Do?

Motorola, at its option, will at no charge repair, replace or refund the purchase price of any Products, Accessories or Software that does not conform to this warranty. We may use functionally equivalent reconditioned/refurbished/pre-owned or new Products, Accessories or parts. No data, software or applications added to your Product, Accessory or Software, including but not limited to personal contacts, games and ringer tones, will be reinstalled. To avoid losing such data, software and applications please create a back up prior to requesting service.

How to Obtain Warranty Service or Other Information

| | |
|--|---|
| USA | Phones 1-800-331-6456 Pagers 1-800-548-9954 Two-Way Radios and Messaging Devices 1-800-353-2729 |
| Canada | All Products 1-800-461-4575 |
| TTY | 1-888-390-6456 |
| For Accessories and Software , please call the telephone number designated above for the product with which they are used. | |

You will receive instructions on how to ship the Products, Accessories or Software, at your expense, to a Motorola Authorized Repair Center. To obtain service, you must include: (a) a copy of your receipt, bill of sale or other comparable proof of purchase; (b) a written description of the problem; (c) the name of your service provider, if applicable; (d) the name and location of the installation facility (if applicable) and, most importantly; (e) your address and telephone number.

What Other Limitations Are There?

ANY IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY, OTHERWISE THE REPAIR, REPLACEMENT, OR REFUND AS PROVIDED UNDER THIS EXPRESS LIMITED WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER, AND IS PROVIDED IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. IN NO EVENT SHALL MOTOROLA BE LIABLE, WHETHER IN CONTRACT OR TORT (INCLUDING NEGLIGENCE) FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT, ACCESSORY OR SOFTWARE, OR FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY KIND, OR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATA, SOFTWARE OR APPLICATIONS OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE ABILITY OR INABILITY TO USE THE PRODUCTS, ACCESSORIES OR SOFTWARE TO THE FULL EXTENT THESE DAMAGES MAY BE DISCLAIMED BY LAW.

Some states and jurisdictions do not allow the limitation or exclusion of incidental or consequential damages, or limitation on the length of an implied warranty, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state or from one jurisdiction to another.

Laws in the United States and other countries preserve for Motorola certain exclusive rights for copyrighted Motorola software such as the exclusive rights to reproduce and distribute copies of the Motorola software. Motorola software may only be copied into, used in, and redistributed with, the Products associated with such Motorola software. No other use, including without limitation disassembly of such Motorola software or exercise of the exclusive rights reserved for Motorola, is permitted.

Hearing Aid Compatibility with Mobile Phones

Some Motorola phones are measured for compatibility with hearing aids. If the box for your particular model has “Rated for Hearing Aids” printed on it, the following explanation applies.

When some mobile phones are used near some hearing devices (hearing aids and cochlear implants), users may detect a buzzing, humming, or whining noise. Some hearing devices are more immune than others to this interference noise, and phones also vary in the amount of interference they generate.

The wireless telephone industry has developed ratings for some of their mobile phones, to assist hearing device users in finding phones that may be compatible with their hearing devices. Not all phones have been rated. Phones that are rated have the rating on their box or a label on the box.

The ratings are not guarantees. Results will vary depending on the user’s hearing device and hearing loss. If your hearing device happens to be vulnerable to interference, you may not be able to use a rated phone successfully. Trying out the phone with your hearing device is the best way to evaluate it for your personal needs.

M-Ratings: Phones rated M3 or M4 meet FCC requirements and are likely to generate less interference to hearing devices than phones that are not labeled. M4 is the better/higher of the two ratings.

T-Ratings: Phones rated T3 or T4 meet FCC requirements and are likely to be more usable with a hearing device’s telecoil (“T Switch” or “Telephone Switch”) than unrated phones. T4 is the better/higher of the two ratings. (Note that not all hearing devices have telecoils in them.)

Hearing devices may also be measured for immunity to this type of interference. Your hearing device manufacturer or hearing health

professional may help you find results for your hearing device. The more immune your hearing aid is, the less likely you are to experience interference noise from mobile phones.

Information from the World Health Organization

Present scientific information does not indicate the need for any special precautions for the use of mobile phones. If you are concerned, you may want to limit your own or your children's RF exposure by limiting the length of calls or by using handsfree devices to keep mobile phones away from your head and body.

Source: WHO Fact Sheet 193

Further information: <http://www.who.int./peh-emf>

Product Registration

Online Product Registration:

<http://www.motorola.com/warranty>

Product registration is an important step toward enjoying your new Motorola product. Registering helps us facilitate warranty service, and permits us to contact you should your product require an update or other service. Registration is for U.S. residents only and is not required for warranty coverage.

Please retain your original dated sales receipt for your records. For warranty service of your Motorola Personal Communications Product you will need to provide a copy of your dated sales receipt to confirm warranty status.

Thank you for choosing a Motorola product.

Export Law Assurances

This product is controlled under the export regulations of the United States of America and Canada. The Governments of the United States of America and Canada may restrict the exportation or re-exportation of this product to certain destinations. For further information contact the U.S. Department of Commerce or the Canadian Department of Foreign Affairs and International Trade.

Wireless: The New Recyclable

Your wireless phone can be recycled. Recycling your wireless phone reduces the amount of waste disposed in landfills and allows recycled materials to be incorporated into new products.

The Cellular Telecommunications Industry Association (CTIA) and its members encourage consumers to recycle their phones and have taken steps to promote the collection and environmentally sound recycling of end-of-life wireless devices.

As a wireless phone user, you have an important role in ensuring that this phone is recycled properly. When it comes time to give this phone up or trade it in for a new one, please remember that the phone, the charger, and many of its accessories can be recycled. It's easy. To learn more about CTIA's Recycling Program for Used Wireless Devices, please visit us at <http://promo.motorola.com/recycle/phones/whyrecycle.html>

Smart Practices While Driving

Drive Safe, Call Smart SM

Check the laws and regulations on the use of mobile devices and their accessories in the areas where you drive. Always obey them. The use of these devices may be prohibited or restricted in certain areas. Contact www.motorola.com/callsmart for more information.

Your mobile device lets you communicate by voice and data—almost anywhere, anytime, wherever wireless service is available and safe conditions allow. When driving a car, driving is your first responsibility. If you choose to use your mobile device while driving, remember the following tips:

- **Get to know your Motorola mobile device and its features such as speed dial and redial.** If available, these features help you to place your call without taking your attention off the road.
- **When available, use a handsfree device.** If possible, add an additional layer of convenience to your mobile device with one of the many Motorola Original™ handsfree accessories available today.
- **Position your mobile device within easy reach.** Be able to access your mobile device without removing your eyes from the road. If you receive an incoming call at an inconvenient time, if possible, let your voice mail answer it for you.
- **Let the person you are speaking with know you are driving; if necessary, suspend the call in heavy traffic or hazardous weather conditions.** Rain, sleet, snow, ice, and even heavy traffic can be hazardous.
- **Do not take notes or look up phone numbers while driving.** Jotting down a “to do” list or going through your address book

takes attention away from your primary responsibility—driving safely.

- **Dial sensibly and assess the traffic; if possible, place calls when your car is not moving or before pulling into traffic.** If you must make a call while moving, dial only a few numbers, check the road and your mirrors, then continue.
- **Do not engage in stressful or emotional conversations that may be distracting.** Make people you are talking with aware you are driving and suspend conversations that can divert your attention away from the road.
- **Use your mobile device to call for help.** Dial 911 or other local emergency number in the case of fire, traffic accident, or medical emergencies.*
- **Use your mobile device to help others in emergencies.** If you see an auto accident, crime in progress, or other serious emergency where lives are in danger, call 911 or other local emergency number, as you would want others to do for you.*
- **Call roadside assistance or a special non-emergency wireless assistance number when necessary.** If you see a broken-down vehicle posing no serious hazard, a broken traffic signal, a minor traffic accident where no one appears injured, or a vehicle you know to be stolen, call roadside assistance or other special non-emergency wireless number.*

* Wherever wireless phone service is available.

motorola.com