



## **HTC Touch Easy E-Mail Setup** **(For Gmail e-mail service)**

Rogers makes setting up your wireless e-mail service quick and easy. Before beginning, please ensure you have everything you need to begin enjoying the time-saving benefits and convenience of sending and receiving wireless e-mail on the go.

### **Wireless E-mail Checklist:**

E-mail-capable wireless device    E-mail Plan    ISP-based E-mail Address

#### **STEP 1      Insert the SIM card and the battery into your wireless device**

- Charge your device for 20 minutes

#### **STEP 2      Turn on your wireless device**

- Ensure **EDGE** or **GPRS** appears on screen (indicates device is connected to the Rogers wireless network)

#### **STEP 3      Set up your wireless e-mail service**

- Follow these steps for [Gmail](#):
  1. Log in to your Gmail account from your PC.
  2. Select **Settings** at the top of any Gmail page.
  3. Select the **Forwarding and POP** tab in the orange Mail Settings box.
  4. Under **POP Download**, choose to **Enable POP for all mail or Enable POP only for mail that arrives from now on**.
  5. Specify whether you want Gmail to keep a copy of messages in the Inbox when you access messages through POP.
  6. Select **Save Changes**.

Now you can **auto-configure Gmail** from your device:

1. On your device, **Select Start -> Messaging**
2. Select **New E-Mail Account**
3. Enter your e-mail address (ie: [yourname@gmail.com](#)) and select **Next** (Ensure 'Try to get e-mail settings automatically from the internet' is checked)
4. Auto Setup will find the settings for gmail.com. Select **Next**
5. Enter your name and select **Next**
6. Enter your password and select **Next** (Check **Save password**, so you don't have to enter it every time you check e-mail)
7. Select how often you would like the device to send/receive e-mail and select **Finish**

#### **STEP 4      You are now ready to send/receive e-mail**

### **Need Help?**

For free 24/7 technical support:

For online help, FAQs & user guides:

For device-specific instructions:

1 866 931-DATA (3282)

[www.rogers.com/techsupport](http://www.rogers.com/techsupport)

Refer to your device's user guide

# **HTC Touch Easy E-Mail Setup** **(For Gmail e-mail service)**

Wireless e-mail service requires an e-mail-capable wireless device activated on the Rogers Wireless network and a subscription to an E-mail Plan. For more information, visit [www.rogers.com/wirelessemail](http://www.rogers.com/wirelessemail).

<sup>TM</sup>Trademarks used under license. © 2007