

## Camera

### To take a picture


1. Press and hold **[Camera]** to start the camera. Make sure the camera icon is highlighted.
  2. Press **[Camera]** to take a picture. The picture is saved in the file manager.
- To take another picture, press **[Camera]** or press **[Back]** to return to the viewfinder.
  - To deactivate the camera, press and hold **[Back]**.



### To take a self-portrait

1. Close the phone and hold it with the external screen and the camera turned towards you.
  2. Press and hold **[Camera]** to start the camera.
  3. Press **[Camera]** again to take the picture.
- Make sure that you have selected the camera, and not the video recorder.

### Camera overview



### To record a video clip

Activate the video recorder. Make sure the video recorder icon is highlighted.



1. Press **[Camera]** to start the recording.
- To end the recording, press **[Camera]**. The video clip is saved in the file manager.
  - To deactivate the video recorder, press and hold **[Back]**.

### Camera and video options

When you are in the viewfinder **[More]** to view a number of options to adjust and enhance your pictures and video clips before taking or recording them.

For more details see additional guides available at [www.SonyEricsson.com/support](http://www.SonyEricsson.com/support).

## VideoDJ™

Using the VideoDJ™, you can edit your video clips, as well as create movies out of clips and pictures saved in your phone.

### To create a movie

1. **[Entertainment] > [VideoDJ™] > [Add]**. Select to add a video clip, a picture or text to your storyboard **[Select]**.
2. **[More] > [Preview]** to take a look at the result and **[More] > [Save]** to save the movie. Movies are saved in the file manager.

### To send a movie

You can send a movie from the storyboard view or from within the Videos folder in the file manager. **[More] > [Send]** and select a transfer method.



## Z520 Quick Guide




## Battery and SIM

- 1 Remove the battery cover.



- 2 Slide the SIM card into its holder.



- 3 Place the battery with the label side up and the connectors facing each other.




- 4 Slide the battery cover into place.




- 5 Connect the charger to the phone.



- 6 It may take up to 30 minutes before the battery icon appears on the screen.



- 7 Wait approximately 4 hours for the battery to be fully charged.



- 8 Remove the charger by pulling it straight out.



## To turn on the phone

1. Open the flip.
2. Press and hold **Ⓚ**.  
The first start-up may take a couple of minutes.
3. Enter your SIM card PIN, if required.
4. At first start-up, select the language you want for your phone menus.



- ▶ Yes if you want the setup wizard to help you get started, and follow the instructions that appear to complete the setup.

## Media player

The media player works as a music player and video player all in one.

### To play music and videos

- ▶ Media Player and select a playlist ▶ Open ▶ Play. The playlist keeps on playing until you press Pause or Stop.

### Media player control

- ▶ Pause to pause the playback.
- Press **⏩** to go forward to the next music track or video clip.
- Press **⏪** to go back to the previous music track or video clip.
- Press and hold **⏩** or **⏪** to fast forward or rewind.
- Press **⏮** or **⏭** to scroll through the playlist during playback. Files that are highlighted will not be selected until you press Stop and Play.
- When a video clip is paused, press **⏪** to play the video clip one frame at a time.



## Light effects

Use the Light effects feature to personalize your phone. Associate light effects with contacts in your phonebook. Set the light effects to notify you of an upcoming event, a missed call or new message.

Certain light effects cannot be turned off, such as open and close the phone, and attach and detach an accessory.

### To add a light effect to a phone contact

1. ▶ Contacts and select the contact you want to add a light effect to ▶ More ▶ Edit Contact.
2. Use **⏮**, **⏪**, **⏩** and **⏭** to scroll to the relevant tab. ▶ Light Effects ▶ Add.
3. Select a light effect ▶ Save to save the contact.



## Synchronization

You can synchronize your phone contacts, appointments, tasks and notes with similar programs in a computer or mobile phone using Bluetooth™ wireless technology, infrared port or the optional USB cable.

Please visit [www.SonyEricsson.com/support](http://www.SonyEricsson.com/support) to download the synchronization software and getting started guides on synchronization.

## Downloading settings

Settings for Internet, messaging, My friends or PlayNow™ may already be entered when you buy your phone. If not, contact your network operator or service provider for more information. Settings are also available at [www.SonyEricsson.com/support](http://www.SonyEricsson.com/support).